



# Woven Summer Halter Top

Woven Summer Halter Top   Verified open pattern specification

Garment Type: Halter Top | Difficulty: Beginner | Provenance: Threadline Open Design Studio | License: CC BY-SA 4.0

## PRINTER CALIBRATION & SCALE VERIFICATION

Measure both test squares with a rigid ruler before cutting fabric. Print at 100% scale without shrinking.



- Scale Rules:
- 1. Open in Acrobat Reader
  - 2. Select Actual Size 100%
  - 3. Do NOT Fit to Page
  - 4. Verify dimensions above

## SIZE SELECTION & EASE RECOMMENDATIONS

Select size based on full bust/chest measurement.  
+4 to +8 cm positive wearing ease for comfortable drape.

## STANDARD BODY MEASUREMENTS CHART

| Size Range      | XS    | S     | M      | L      | XL     | 2XL    | 3XL    |
|-----------------|-------|-------|--------|--------|--------|--------|--------|
| Full Bust/Chest | 80 cm | 86 cm | 92 cm  | 98 cm  | 108 cm | 118 cm | 128 cm |
| Full Hip / Seat | 88 cm | 94 cm | 100 cm | 106 cm | 116 cm | 126 cm | 136 cm |

## FINISHED MEASUREMENTS & MATERIALS

### FINISHED GARMENT MEASUREMENTS (INCLUDES DESIGN EASE)

| Dimension      | XS    | S     | M     | L      | XL     | 2XL    | 3XL    |
|----------------|-------|-------|-------|--------|--------|--------|--------|
| Finished Chest | 84 cm | 90 cm | 96 cm | 102 cm | 112 cm | 122 cm | 132 cm |
| Hem Sweep      | 72 cm | 78 cm | 84 cm | 90 cm  | 100 cm | 110 cm | 120 cm |
| Garment Length | 44 cm | 45 cm | 46 cm | 48 cm  | 50 cm  | 52 cm  | 54 cm  |

### FABRIC REQUIREMENTS (45 IN / 115 CM & 60 IN / 150 CM BOLTS)

| Bolt Width          | XS      | S       | M       | L      | XL     | 2XL    | 3XL    |
|---------------------|---------|---------|---------|--------|--------|--------|--------|
| 45" / 115 cm Fabric | 1 yd    | 1 yd    | 1 yd    | 1.2 yd | 1.2 yd | 1.4 yd | 1.4 yd |
| 60" / 150 cm Fabric | 0.85 yd | 0.85 yd | 0.85 yd | 1 yd   | 1 yd   | 1.2 yd | 1.2 yd |

### RECOMMENDED FABRICS & STRETCH PROPERTIES

Recommended Substrates: 100% washed linen 150 180 gsm, Cotton lawn or batiste, Viscose / rayon challis. Stretch Requirement: None 0% stable woven.

### NOTIONS & SEWING TOOLS CHECKLIST

- ☐ Matching all-purpose thread
- ☐ Universal needle size 70/10 or 80/12
- ☐ 25 mm 1 in knit elastic for back band
- ☐ Lightweight fusible interfacing for facing set
- ☐ Sharp fabric shears
- ☐ Measuring tape
- ☐ Iron and pressing ham

## PATTERN INVENTORY & CUTTING LAYOUT

### STANDARD SEAM & HEM ALLOWANCES

Use the seam and hem allowances printed on each pattern piece. Verify every allowance label before cutting fabric.

### PATTERN PIECE INVENTORY & CUTTING SCHEDULE

| Piece Name          | Cut Quantity                | Material / Interfacing |
|---------------------|-----------------------------|------------------------|
| Halter Front Bodice | Cut 1 on Fold in Fabric     | Main Fabric            |
| Halter Back Band    | Cut 1 on Fold in Fabric     | Main Fabric            |
| Neck Ties           | Cut 1 Pair in Fabric        | Main Fabric            |
| Front Halter Facing | Cut 1 on Fold + Interfacing | Main Fabric            |
| Back Band Facing    | Cut 1 on Fold + Interfacing | Main Fabric            |

### FABRIC PREPARATION & CUTTING RULES

- Press fabric before cutting to remove packing folds and pre-shrink fibers.
- Align piece grainlines strictly parallel to fabric selvages.
- Transfer notch markings with small 3 mm snips into the seam allowance margin.

### MULTI-PAGE TILE ASSEMBLY INSTRUCTIONS

1. Check Sheet 1 calibration square before printing the remaining pattern sheets.
2. Trim right and bottom border lines along the dashed perimeter frame.
3. Match corner crosshairs, such as A1 to A2 and B1 to B2, without overlapping.
4. Tape sheets securely on both sides before cutting paper pieces.

## STEP-BY-STEP SEWING INSTRUCTIONS

### Step 1: Construct Neck Ties

Fold neck tie strips lengthwise right sides together. Stitch along long edge and one short end, trim corner, turn right side out using a loop turner, and press crisp.

### Step 2: Prepare Facing & Baste Ties

Fuse interfacing to front and back facing pieces. Baste the raw ends of the finished neck ties to the upper neck peaks of the front bodice facing toward center.

### Step 3: Attach Facing & Encase Neckline

Pin front facing to front bodice right sides together, sandwiching the neck ties.

Stitch upper halter neckline and curved underarm edges. Clip curves, turn right side out, and understitch facing.

### Step 4: Construct Elasticated Back Band

Stitch back band into a casing channel. Thread 25 mm elastic through, distribute gathers evenly, and secure elastic ends with vertical staystitches.

### Step 5: Side Seams & Curved Hem

Join front bodice and elasticated back band at side seams right sides together, enclosing facing raw edges. Press seams open. Turn narrow double-fold hem along bottom edge and topstitch.

## TROUBLESHOOTING & PRO SEWING TIPS

### Issue: Seams puckering along stitch line

Fix: Insert fresh needle and test balance on fabric scrap.

### Issue: Wavy edge along curved perimeter

Fix: Staystitch immediately after cutting and use walking foot.