


Unisex Chef Apron with Split Leg

Unisex Chef Apron with Split Leg Verified open pattern specification

Garment Type: Chef Apron | Difficulty: Confident Beginner | Provenance: Threadline Open Design Studio | License: CC BY-SA 4.0

PRINTER CALIBRATION & SCALE VERIFICATION

Measure both test squares with a rigid ruler before cutting fabric. Print at 100% scale without shrinking.



Scale Rules:

- 1. Open in Acrobat Reader
- 2. Select Actual Size 100%
- 3. Do NOT Fit to Page
- 4. Verify dimensions above

SIZE SELECTION & EASE RECOMMENDATIONS

Universal adjustable fit suitable for adult chest measurements 80 135 cm.

Generous protective coverage designed to wrap around torso and thighs.

UNIVERSAL FIT / ACCESSORY SPECIFICATION

Universal sizing designed to fit diverse bodies without standard body grading charts. See Page 2.

FINISHED MEASUREMENTS & MATERIALS

FINISHED GARMENT MEASUREMENTS (INCLUDES DESIGN EASE)

Dimension	Universal / One Size
Apron Body Length	94 cm
Apron Width / Sweep	90 cm
Tie / Strap Length	160 cm

FABRIC REQUIREMENTS (45 IN / 115 CM & 60 IN / 150 CM BOLTS)

Bolt Width	Universal / One Size
45" / 115 cm Fabric	1.95 yd
60" / 150 cm Fabric	1.55 yd

RECOMMENDED FABRICS & STRETCH PROPERTIES

Recommended Substrates: 10 14 oz Heavy cotton canvas, denim, or wax duck cloth.

Stretch Requirement: None 0% stable woven.

NOTIONS & SEWING TOOLS CHECKLIST

- ☐ Matching all-purpose polyester or cotton sewing thread
- ☐ Universal sewing needle size 80/12
- ☐ Sharp fabric shears
- ☐ Measuring tape
- ☐ Iron and pressing ham

PATTERN INVENTORY & CUTTING LAYOUT

STANDARD SEAM & HEM ALLOWANCES

Use the seam and hem allowances printed on each pattern piece. Verify every allowance label before cutting fabric.

PATTERN PIECE INVENTORY & CUTTING SCHEDULE

Piece Name	Cut Quantity	Material / Interfacing
Apron Main Body	Cut 1 on Fold	Main Fabric
Bib Patch Pocket	Cut 1 in Canvas	Main Fabric
Divided Tool Waist Pocket	Cut 1 in Canvas	Main Fabric
Cross-Back Straps	Cut 2 in Heavy Webbing or Canvas	Main Fabric

FABRIC PREPARATION & CUTTING RULES

- Press fabric before cutting to remove packing folds and pre-shrink fibers.
- Align piece grainlines strictly parallel to fabric selvages.
- Transfer notch markings with small 3 mm snips into the seam allowance margin.

MULTI-PAGE TILE ASSEMBLY INSTRUCTIONS

1. Check Sheet 1 calibration square before printing the remaining pattern sheets.
2. Trim right and bottom border lines along the dashed perimeter frame.
3. Match corner crosshairs, such as A1 to A2 and B1 to B2, without overlapping.
4. Tape sheets securely on both sides before cutting paper pieces.

STEP-BY-STEP SEWING INSTRUCTIONS

Step 1: Hem Apron Edges

Turn under and stitch 10 mm double rolled hem along curved side edges and bottom hem.

Step 2: Prepare Pockets

Hem top edges of bib and tool pockets. Press sides and bottom under 10 mm.

Step 3: Attach Pockets

Position pockets on apron body markings. Topstitch perimeter at 3 mm and 6 mm. Stitch vertical pocket dividers.

Step 4: Attach Straps & Hardware

Anchor Cross-Back Straps at upper bib corners right sides together with reinforced Box-X stitch. Stitch waist tie loops and press seam allowances.

TROUBLESHOOTING & PRO SEWING TIPS

Issue: Seams puckering along stitch line

Fix: Insert fresh needle and test balance on fabric scrap.

Issue: Wavy edge along curved perimeter

Fix: Staystitch immediately after cutting and use walking foot.